

UPOFLOOR®

MAINTENANCE

UPOFLOOR LIFELINE

Initial cleaning

For LifeLine tiles allow the adhesive sufficient time to dry, wet-cleaning methods should not be used until a week after installation.

First remove loose dirt. Wash the floor using mild alkaline or alkaline detergent in water. A combination machine or a floor care machine with red pads can be used. Avoid excessive use of water. Clean floor can be treated with a maintenance cleaner solution.

Polishing

Polishing is not required.

Periodic maintenance

First remove loose dirt. Use a moist-cleaning method or a combination machine with red pads when necessary. The cleaning solution should be mildly alkaline. SHS-machine with tensid or polymer based cleaning and care maintenance agent is also recommended periodically.