

## MAINTENANCE

### UPOFLOOR ESTRAD ESD

#### Initial cleaning

Remove loose dirt through dry or damp cleaning. Clean the floor with a combination machine or a floor cleaning machine with red pads or with medium hard brushes. Use alkaline detergent containing glycols, such as a wax removal agent. Follow the product manufacturer's dosage guidelines.

#### Polishing

Estrad ESD floorings in health care premises are not recommended to be polished. You can treat the cleaned floor with an SHS machine together with a maintenance agent or by dry puffing. NB! The gloss level of the surface will increase considerably and permanently.

If you want to polish the floor for example in industrial premises, use one coat of ESD polish. A second coat of polish may change the conductivity of the flooring. Localised polishing is not recommended since layering the polish should be avoided.

#### Daily maintenance

Perform dry or damp cleaning. Increase dampness to clean hard-to-remove soiling. Use a combination machine to treat larger surfaces and an SHS machine to treat smaller surfaces. Use red pads in the machine. Use a mild alkaline cleaning and maintenance agent.

#### Basic cleaning

Wash heavily soiled floors with an alkaline solution or with a strong alkaline solution where necessary. Use a floor cleaning machine or a combination machine with red pads. Rinse carefully. When necessary, clean and dry floor can be treated with an SHS machine and a maintenance agent. After basic cleaning, polished floors can be treated with a one coat of ESD polish.